

AL-AVAL2-14CLHO

Manual/Fitting Instructions



1. Red Lead to Constant Power
2. Black Lead to Earth
3. Green Lead to Operating Indicator
4. White Lead to other side of flasher unit to mute
5. Orange to switch on dashboard for half volume